05H07–01

SYSTEM DIAGRAM

Transmitting ECU (transmitter)	Receiving ECU	Signals	Communication method
ECM	Combination Meter ECU	CRUISE indicator operation signal	CAN BEAN (Instrument Panel Bus)



I36961
N

I40237