GENERATOR ASSY

190UZ–01

COMPONENTS




2.3 (24, 20 in.·lbf)
Generator Drive End Frame
Generator Washer
Bearing Cover
◆ Front Bearing
Generator Pulley
Bearing Cover
◆ Rear Bearing
Generator Rotor Assy
Retainer
Cord Clip
4.6 (47, 41 in.·lbf)
5.8 (59, 51 in.·lbf)
111 (1132, 82)
Front Seal Plate
Terminal Insulator
Generator Rear End Cover
Rear Seal Plate
1.8 (18, 16 in.·lbf)
Generator Brush Holder Assy
Generator Coil Assy
N·m (kgf·cm, ft·lbf) : Specified torque
◆ Non–reusable part
Y
A93996