Position of Parts in Seat <LHD Rear No.2 Seat From Sep. 2015 Production>



h	1	Seat Back Lock Switch RH No.1
h	2	Seat Back Release Motor RH No.1
h	3	Seat Back Release Motor RH No.2
h	4	Seat Back Area Switch RH
h	5	Seat Back Lock Switch RH No.2
h	6	Seat Back Lock Switch LH No.1
h	7	Seat Back Release Motor LH No.1
h	8	Seat Back Release Motor LH No.2
h	9	Seat Back Area Switch LH
h	10	Seat Back Lock Switch LH No.2
i	1	Rear No.2 Seat Retract Motor RH
i	2	Rear No.2 Seat Retract Motor RH
i	3	Fold Seat Control ECU RH
i	4	Fold Seat Control ECU RH
i	6	Floor Release Motor RH
i	7	Floor Striker Limit Switch RH No.1
i	8	Floor Striker Limit Switch RH No.2
i	9	Rear No.2 Seat Retract Motor LH
i	10	Rear No.2 Seat Retract Motor LH
i	11	Fold Seat Control ECU LH
i	12	Fold Seat Control ECU LH
i	13	Fold Seat Control ECU LH
i	14	Floor Release Motor LH
i	15	Floor Striker Limit Switch LH No.1
i	16	Floor Striker Limit Switch LH No.2

h 1
White



h 2
White



h 3
White



h 4
Blue



h 5
Black



h 6
Black



h 7
White



h 8
White



h 9
Blue



h 10
White



i 1
White



i 2
White



i 3
White



i 4
White



i 6
White



i 7
White



i 8
Black



i 9
White



i 10
White



i 11
White



i 12
White



i 13
White



i 14
White



i 15
White



i 16
Black