
* 3:Before Jan. 2012 Production
* 4:From Jan. 2012 Production
(*3) N8
(*4) N13
(*3) N9
(*4) N14
N6
N1
(*3) N2
(*4) N12
N5
N4
g2
f3
f1
X1
e1
f2
e2
O5
(*3) O1
(*4) O7
f4
N10
N11
N7
g1
N3
O6
O4 (*3)
O10 (*4)
M2
f5
O3 (*3)
O9 (*4)
O2 (*3)
O8 (*4)

M 2 Fuel Sender Gauge Assembly (Sub)

N 1 Fuel Pump , Fuel Sender Gauge Assembly (Main)
N 2 Fuel Pump Control ECU Assembly
N 3 No.1 Height Control Valve Assembly
N 4 Rear Height Control Sensor Sub-Assembly RH
N 5 Rear Shock Absorber Assembly RH
N 6 Rear Height Control Sensor Sub-Assembly LH
N 7 Rear Shock Absorber Assembly LH
N 8 Front Shock Absorber Assembly RH
N 9 Front Shock Absorber Control Valve Assembly RH
N 10 Front Shock Absorber Assembly LH
N 11 Front Shock Absorber Control Valve Assembly LH
N 12 Fuel Pump Control ECU Assembly
N 13 Front Shock Absorber Assembly RH
N 14 Front Shock Absorber Control Valve Assembly LH

O 1 No.2 Ultrasonic Sensor RH
O 2 No.3 Ultrasonic Sensor RH
O 3 No.3 Ultrasonic Sensor LH
O 4 No.2 Ultrasonic Sensor LH
O 5 Rear Fog Light Assembly RH
O 6 Rear Fog Light Assembly LH
O 7 No.2 Ultrasonic Sensor RH
O 8 No.3 Ultrasonic Sensor RH
O 9 No.3 Ultrasonic Sensor LH
O 10 No.2 Ultrasonic Sensor LH

X 1 Front Seat Memory Switch LH

e 1 Fuel Temperature Sensor
e 2 Pressure Accumulator Sensor

f 1 Back Door Remote Control Assembly
f 2 Tail Gate Lock Assembly Lower RH
f 3 Tail Gate Lock Assembly Lower LH
f 4 Back-Up Light Assembly RH
f 5 Back-Up Light Assembly LH

g 1 Step Light Assembly LH
g 2 Step Light Assembly RH

M 2
Black

N 1
White

N 2
Gray



N 3
Black



N 4
Black



N 5
Gray

N 6
Black



N 7
Gray



N 8
Gray



N 9
Gray

N 10
Gray



N 11
Gray

N 12
Black



N 13
Gray

N 14
Gray

O 1
Black



O 2
Black



O 3
Black



O 4
Black



O 5
White



O 6
White



O 7
Black



O 8
Black



O 9
Black



O 10
Black



X 1
White



e 1
Gray

e 2
Black



f 1
Black



f 2
White



f 3
Gray



f 4
Gray



f 5
Gray



g 1
White

g 2
White