Position of Parts in Seat <RHD Front Seat Before Sep. 2015 Production>



* 1:Before Jan. 2012 Production
* 2:From Jan. 2012 Production

K 5 Front Side Airbag Squib Circuit LH
K 10 Front Seat Inner Belt Assembly LH
K 47 Front Side Airbag Squib Circuit LH

L 15 Front Side Airbag Squib Circuit RH
L 48 Front Seat Inner Belt Assembly RH
L 58 Front Side Airbag Squib Circuit RH

c 1 Front Seat Heater Assembly RH
c 3 Front Power Seat Slide Position Motor Assembly RH
c 4 Front Power Seat Lift Position Motor Assembly RH
c 5 Front Power Seat Vertical Position Motor Assembly RH
c 6 Front Power Seat Reclining Position Motor Assembly RH
c 7 Front Seat Inner Belt Assembly RH
c 12 Junction Connector
c 13 Front Seat Heater Assembly LH
c 16 Front Power Seat Switch Assembly LH
c 17 Front Power Seat Slide Position Motor Assembly LH
c 18 Front Power Seat Lift Position Motor Assembly LH
c 19 Front Power Seat Vertical Position Motor Assembly LH
c 20 Front Power Seat Reclining Position Motor Assembly LH
c 21 Front Lumbar Support Forward and Back Motor Assembly LH
c 22 Front Seat Inner Belt Assembly LH
c 23 Junction Connector
c 24 Front Seat Climate Control ECU RH
c 25 Front Seat Climate Control ECU RH
c 26 Front Seat Climate Controller Seat Cushion RH
c 27 Front Seat Climate Controller Seat Back RH
c 28 Front Seat Climate Control Blower RH
c 29 Front Seat Heater Assembly RH
c 30 Front Power Seat Switch Assembly RH
c 31 Front Lumbar Support Forward and Back Motor Assembly RH
c 32 Rear Foot Light RH (No.1 Interior Illumination Light Assembly)
c 36 Seat Cushion Switch
c 38 Front Seat Climate Control ECU LH
c 39 Front Seat Climate Control ECU LH
c 40 Front Seat Climate Controller Seat Cushion LH
c 41 Front Seat Climate Controller Seat Back LH
c 42 Front Seat Climate Control Blower LH
c 43 Front Seat Heater Assembly LH
c 44 Front Power Seat Cushion Control Motor Assembly RH
c 46 Front Seat Inner Belt Assembly LH
c 47 Front Power Seat Switch Assembly LH
c 48 Rear Foot Light LH (No.1 Interior Illumination Light Assembly)
c 49 Front Power Seat Control ECU and Switch RH
c 50 Front Power Seat Control ECU and Switch RH
c 51 Front Seat Inner Belt Assembly RH
c 53 Front Seat Inner Belt Assembly LH
c 55 Front Seat Climate Control ECU RH
c 56 Front Seat Climate Control ECU LH
c 57 Front Power Seat Control ECU and Switch RH
c 58 Front Power Seat Control ECU and Switch RH
c 59 Front Power Seat Slide Position Motor Assembly RH
c 60 Television Display Assembly RH
c 61 Television Display Assembly LH

Position of Parts in Seat <RHD Front Seat Before Sep. 2015 Production>

K 5
Yellow



K 10
Gray



K 47
Yellow



L 15
Yellow



L 48
Gray



L 58
Yellow



c 1
White



c 3
White



c 4
White



c 5
White



c 6
White



c 7
White



c 12
White



c 13
White



c 16
White



c 17
White



c 18
White



c 19
White



c 20
White



c 21
White



c 22
White



c 23
White



c 24
White



c 25
White



c 26
Blue



c 27
White



c 28
White



c 29
White



c 30
White



c 31
White



c 32
Black



c 36
Black



c 38
White



c 39
White



c 40
Blue



c 41
White



c 42
White



c 43
White



c 44
Black



c 46
White



c 47
Black



c 48
Black



c 49
Gray



c 50
White



c 51
Gray



c 53
Gray



c 55
White



c 56
White



c 57
White



c 58
White



c 59
White



c 60
White



c 61
White