ANTI–LOCK BRAKE SYSTEM

DI13F–01

HOW TO PROCEED WITH TROUBLESHOOTING

Troubleshoooting in accordance with the procedure on the following pages.



Step 8: Diagnostic steps permitting the use of the LEXUS hand–held tester or LEXUS break–out–box.