AC1JW–04

LOCATION



P


Front Cooling Unit
• Expansion Valve
• Evaporator
• Evaporator Temperature Sensor
• Air Refiner Filter
Cowl Side J/B LH
• ACC Fuse
w/ EMV:
Front Heater Unit
• Air Mix Servomotor
• Air Outlet Servomotor
• Heater Radiator
• Air Refiner FIlter
Room Temperature Sensor (for Rear A/C)
Solar Sensor
Rear A/C Control Assembly
A/C Amplifier
Integration Control Panel
Cowl Side J/B RH
• RR A/C
Blower Unit
• Air Inlet Servomotor
• Blower Motor
• Blower Motor Control Relay
A/C Control Assembly
Rear Cooling Unit
• A/C Amplifier
• Blower Motor
• Power Transistor
• Evaporator
• Thermistor
• Expansion Valve
Rear Heater Unit
• Blower Motor
• Power Transistor
• Air Mix Servomotor
• Heater Radiator
• Air Inlet Temperature Sensor
Room Temperature Sensor (for Front A/C)
P
I24785