② : Engine Room R/B Assembly No. 2	**Left Engine Compartment**
⬭ : Engine Room J/B Assembly No. 2	



Unit A


* 1:50A FAN LH
* 2:50A IG1-MAIN
* 3:50A FAN RH
IG1 MAIN Relay
INJ NO.2 Relay
2 10A 1
ENG-IG NO.1
2 15A 1
S/HTR F/R
2 5A 1
EPS-IG
2 25A 1
WIPER
2 5A 1
ENG-IG NO.2
2 5A 1
RADAR-IG
2 20A 1
WASHER
1 7.5A 2
ARW SW
1 15A 2
STRG HTR
1 15A 2
MIR HTR
1 10A 2
NOISE FILTER
2 25A 1
INJ NO.1
2 5A 1
STOP
2 10A 1
ETCS
2 10A 1
HORN
2 10A 1
S-HORN
*1
*2
*3
Black
2H
(from Engine Room Main Wire)
White
2I
(from Engine Room Main Wire)

2 : Engine Room R/B Assembly No. 2	**Left Engine Compartment**
: Engine Room J/B Assembly No. 2	

Unit B