
* 1:Before Nov. 2017 Production
* 2:From Nov. 2017 Production
b11
b9
i1
b7
d3
d1
c1
h1
c4
b
b1
b5
b6
i
d
c
h
b4
b2
b10
b8
(*1)
b12
(*2)
b3
d2
d4
c3
c2

b1 Power Seat Slide Motor LH (Front Seat Adjuster Assembly LH)
b2 Power Seat Lift Motor LH (Front Seat Adjuster Assembly LH)
b3 Power Seat Tilt Motor LH (Front Seat Adjuster Assembly LH)
b4 Position Control ECU and Switch Assembly LH
b5 Position Control ECU and Switch Assembly LH
b6 Front Lumbar Power Seat Switch
b7 Seat Heater Assembly LH (Front Seat Cushion with Cover Pad LH)
b8 Seat Cushion Climate Control Blower Assembly LH
b9 Front Seat Inner Belt Assembly LH
b10 Front Limit Switch LH (Front Seat Back Edge Protector)
b11 No. 13 Junction Connector
b12 Seat Cushion Climate Control Blower Assembly LH

c1 Seat Back Climate Control Blower RH
c2 Power Seat Reclining Motor RH (Front Seat Back Spring Sub-Assembly RH)
c3 Lock Limit Switch RH (Front Seat Back Edge Protector)
c4 Power Seat Lumbar Support Motor RH (Front Seat Back Spring Sub-Assembly RH)

d1 Seat Back Climate Control Blower LH
d2 Power Seat Reclining Motor LH (Front Seat Back Spring Sub-Assembly LH)
d3 Power Seat Lumbar Support Motor LH (Lumbar Support Adjuster Assembly LH)
d4 Lock Limit Switch LH (Front Seat Back Edge Protector)

h1 Front Seat Airbag Assembly RH

i1 Front Seat Airbag Assembly LH

Position of Parts in Seat (LHD)

b1
Black



90980-11841

b2
Black



90980-11841

b3
White



90980-12341

b4
Black



90980-11782

b5
White



90980-12552

b6
White



90980-10933

b7
White



90980-11528

b8
White



90980-12180

b9
White



90980-12366

b10
White



90980-11736

b11
White



90980-12346

b12
White



90980-12344

c1
Black



90980-10908

c2
White



90980-12341

c3
Black



90980-11736

c4
Gray



90980-12341

d1
Black



90980-10908

d2
White



90980-12341

d3
Gray



90980-12341

d4
Black



90980-11736

h1
Black



90980-12452

i1
Black



90980-12452