
* 1:w/ LEXUS Navigation System
* 2:w/o LEXUS Navigation System
O4
O25
O42
O19
O37
O36
O24
O22
O30
O23
O31
O41
O38
O26
O21
O39
O27
O14
O5
O32
O3
O11
O6
O7
O28
O29
O20
O18
O34
(*2)
O17
(*1)
O16
O33
(*2)
O15
(*1)
O43

O 3 No. 1 Interior Illumination Light Assembly RH
O 4 Front Door Courtesy Light Switch Assembly RH
O 5 Side Airbag Sensor Assembly RH
O 6 Front Seat Outer Belt Assembly RH
O 7 Front Seat Outer Belt Assembly RH
O 11 Pneumatic with Tube Tank Assembly
O 14 Rear Door Courtesy Light Switch Assembly RH
O 15 Stereo Component Amplifier Assembly
O 16 Stereo Component Amplifier Assembly
O 17 Stereo Component Amplifier Assembly
O 18 Stereo Component Amplifier Assembly
O 19 Rear Side Airbag Squib Circuit RH
O 20 Indoor Luggage Compartment Electrical Key Oscillator
O 21 Rear No. 1 Seat Belt Assembly Outer RH
O 22 Door Control Receiver
O 23 No. 2 Room Light Assembly RH
O 24 Quarter Side Speaker Assembly RH
O 25 Curtain Shield Airbag Assembly RH
O 26 No. 2 Suspension Control Switch
O 27 Height Control Valve Harness Assembly
O 28 Junction Connector
O 29 Junction Connector
O 30 Junction Connector
O 31 Junction Connector
O 32 Front Seat Outer Belt Assembly RH
O 33 Stereo Component Amplifier Assembly
O 34 Stereo Component Amplifier Assembly
O 36 Rear Airbag Sensor RH
O 37 Rear Seat 3 Point Type Belt Assembly RH
O 38 Theft Warning Siren Assembly
O 39 Option Connector (Glass Breakage Sensor ECU Assembly)
O 41 Theft Warning Siren Assembly
O 42 Stereo Component Amplifier Assembly
O 43 Stereo Component Amplifier Assembly

O 3
White

O 4
White

O 5
Yellow



O 6
Black



O 7
White

O 11
Black

O 14
White

O 15
White



O 16
White



O 17
White



O 18
White

O 19
Yellow

O 20
White



O 21
Black



O 22
Blue



O 23
Gray



O 24
White



O 25
Black



O 26
White



O 27
White



O 28
Black



O 29
Blue



O 30
Black



O 31
White



O 32
White



O 33
White



O 34
White



O 36
Yellow



O 37
White



O 38
Black



O 39
White



O 41
Black



O 42
White



O 43
White