
* 1:HID Type
A39
A38
A34
A35
A45
A7
A37
A31
A30
A26
(*1)
A24
A13
A8
A36
A22
A23
A21
A20
(*1)
A18
A16
A12
A33
A40
A41
A32
A42
A28
A6
A29
A1
A3
A9
A2
A11
A5
A10

A 1 Low Pitched Horn Assembly
A 2 High Pitched Horn Assembly
A 3 Cooler (Ambient Temperature Sensor) Thermistor
A 5 Front Airbag Sensor LH
A 6 Front Airbag Sensor RH
A 7 A/C Pressure Sensor
A 8 Security Horn Assembly
A 9 Engine Hood Courtesy Switch
A 10 No. 1 Height Control Valve Sub-Assembly
A 11 Noise Filter
A 12 No. 1 Ultrasonic Sensor (Front Left)
A 13 No. 1 Ultrasonic Sensor (Front Right)
A 16 Fog Light Assembly LH
A 18 Headlight Assembly LH
A 20 Headlight Assembly LH
A 21 Headlight Assembly LH
A 22 Headlight Assembly LH
A 23 Headlight Assembly LH
A 24 Fog Light Assembly RH
A 26 Headlight Assembly RH
A 28 Headlight Assembly RH
A 29 Headlight Assembly RH
A 30 Headlight Assembly RH
A 31 Headlight Assembly RH
A 32 Headlight Cleaner Motor and Pump Assembly
A 33 Headlight Cleaner Control Relay
A 34 Windshield Wiper Motor Assembly
A 35 Front Wiper Deicer (Windshield Glass)
A 36 Front Speed Sensor LH
A 37 Front Speed Sensor RH
A 38 Front Height Control Sensor Sub-Assembly LH
A 39 Front Height Control Sensor Sub-Assembly RH
A 40 Front Windshield Washer Motor and Pump Assembly
A 41 Level Warning Switch Assembly
A 42 Rear Windshield Washer Motor and Pump Assembly
A 45 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Sub-Assembly)

A 1
Black



A 2
Black

A 3
Black

A 5
Yellow



A 6
Yellow



A 7
Black



A 8
Black

A 9
Black

A 10
Black

A 11
Brown



A 12
Black



A 13
Black



A 16
Black



A 18
Gray



A 20
Black



A 21
Black



A 22
Gray



A 23
Gray



A 24
Black



A 26
Gray



A 28
Black



A 29
Black



A 30
Gray



A 31
Gray



A 32
Black

A 33
Gray



A 34
Black



A 35
Gray



A 36
Black



A 37
Black



A 38
Black



A 39
Black



A 40
Gray



A 41
Black



A 42
White



A 45
Gray