: Instrument Panel J/B Assembly	Cowl Side Panel LH



: Instrument Panel J/B Assembly	Cowl Side Panel LH



: Instrument Panel J/B Assembly	Cowl Side Panel LH

View B



: Instrument Panel J/B Assembly	Cowl Side Panel LH

View C

* 1:P/OUTLET NO.1