Position of Parts in Seat (LHD Rear No. 1 Seat)



R18 Rear Seat Airbag Assembly RH
R19 Rear Seat 3 Point Type Belt Assembly RH

S19 Rear Seat Airbag Assembly LH
S20 Rear Seat Belt Inner Assembly LH

V3 USB Jack (Rear Seat Center Armrest Assembly)
V6 Rear Seat Heater Switch

x1 Rear Power Seat Reclining Position Motor RH (Rear Seat Back Frame Sub-Assembly RH)
x2 Rear Power Seat Reclining Position Motor RH (Rear Seat Back Frame Sub-Assembly RH)
x3 Fold Seat Control ECU RH (Rear No. 1 Seat)
x4 Fold Seat Control ECU RH (Rear No. 1 Seat)
x5 Rear Seat Heater Control Sub-Assembly RH
x6 Rear Power Seat Switch RH
x7 Rear Seat 3 Point Type Belt Assembly RH
x8 Rear Seat Inner Belt Assembly Center
x9 Rear Seat Airbag Assembly RH

y1 Rear Power Seat Reclining Position Motor LH (Rear Seat Back Frame Sub-Assembly LH)
y2 Rear Power Seat Reclining Position Motor LH (Rear Seat Back Frame Sub-Assembly LH)
y3 Fold Seat Control ECU LH (Rear No. 1 Seat)
y4 Fold Seat Control ECU LH (Rear No. 1 Seat)
y5 Rear Power Seat Switch LH
y6 Rear Seat Heater Control Sub-Assembly LH
y7 Rear Seat Inner Belt Assembly LH
y8 Rear Seat Airbag Assembly LH

Position of Parts in Seat (LHD Rear No. 1 Seat)

R18
Yellow



90980-12698

R19
White



90980-12366

S19
Yellow



90980-12698

S20
Black



90980-12366

V3
Black



90980-12D25

V6
White



90980-12368

x1
White



90980-12341

x2
White



90980-12344

x3
White



90980-12557

x4
White



90980-12540

x5
White



90980-12344

x6
White



90980-12217

x7
White



90980-12936

x8
White



90980-12936

x9
Yellow



90980-12698

y1
White



90980-12344

y2
White



90980-12341

y3
White



90980-12557

y4
White



90980-12540

y5
White



90980-12217

y6
White



90980-12344

y7
White



90980-12936

y8
Yellow



90980-12698