


INDEX

COMPONENT	LOCATION
ACC CONNECTOR, FUSE	B - 6
ALTERNATOR	B - 12
ALTERNATOR WARNING LIGHT	B - 12
AMP. ENGAGEMENT (COOLER)	B - 29
AUTO CLOCK	B - 25
ANTI-CAPTURING VALVE	B - 13
BACK-UP LIGHT	B - 18
BACK-UP LIGHT SW.	B - 18
BACK-UP LIGHT SWITCH	B - 17
BATTERY	B - 1
BRAKE FAILURE SWITCH	B - 21
BRAKE FAILURE WARNING LIGHT	B - 21
BRAKE FLUID LEVEL WARNING LIGHT	B - 21
BRAKE FLUID LEVEL SENSOR	B - 21
BRAKE SWITCH	B - 25
BULB CHECK RELAY	B - 29
CARBURETTOR HEATER	B - 9
CHARGE WARNING LIGHT	B - 12
CIGARETTE LIGHTER	B - 25
CLOCK ILLUMINATION LIGHT	B - 25
COMBINATION SWITCH ASS'Y.	
CORNER SWITCH	B - 25
COURTESY & PLAFOND SWITCH	B - 25
COURTESY LIGHT	B - 25
COURTESY LIGHT DOOR SWITCH	B - 25
DOOR SIGNAL LIGHT SWITCH	B - 25
DOOR WARNING SWITCH	B - 25
DOOR WINDOW MOTOR	B - 25
COOLANT LEVEL SENSOR	B - 29
COOLER THERMO WARNING LIGHT	B - 29
COOLER RELAY	B - 29
NO. 1	B - 30
NO. 2	B - 30
DOOR SWITCH	B - 25
LEFT FRONT	B - 25
RIGHT FRONT	B - 25
DOOR WARNING SWITCH	B - 25
DOOR LOCK	B - 25
DOOR MOTOR	B - 25
DOOR SWITCH	B - 25
DOOR WINDOW MOTOR	B - 25
DOOR WINDOW SWITCH	B - 25
DOOR WINDOW SWITCH & WARNING LIGHT	B - 25
DRAFT CONTROL VALVE	B - 13
DRAFT CONTROL VALVE SWITCH	B - 13
DRAFT CONTROL VALVE WARNING LIGHT