
AIRBAG CONTROL MODULE
AB7
AB8
PRETENSIONER LH
AB19
INFLATOR (SIDE LH)
AB9
AB29
SIDE AIRBAG SENSOR LH
AB10
SIDE AIRBAG SENSOR RH
AB12
INFLATOR (SIDE RH)
AB11
AB28
LAP SEAT BELT PRETENSIONER
AB30
PRETENSIONER RH
AB20


(YELLOW) AB9
AB11 (YELLOW)
(BLACK) AB19
(BLACK) AB20
AB30 (ORANGE)
AB10 (YELLOW)
AB12 (YELLOW)
AB7 (YELLOW)
AB8 (YELLOW)