(Cont. next page)

Air Conditioner (RHD Automatic A/C)




Air Conditioner (RHD Automatic A/C)
5
6
7
8
(ACC)
7. 5A
RADIO
(BAT)
7. 5A
MPX–B
Multiplex Communication
System (CAN)<2–3>
D19(A), D20(B)
A/C Control Assembly
ACC
+B
CANL
CANH
SG
TR
TAM
TPO
AOD
AOF
TPDr
AMHDr
AMCDr
TPPa
AMHPa
AMCPa
S5
D46(A), D47(B)
Junction Connector
D67
Cooler
(Room Temperature Sensor)
Thermistor
A25
Evaporator Thermistor Sensor
(No. 1 Cooler Thermistor)
A29
No. 3 A/C Radiator Damper Servo
Sub–Assembly
A24
No. 5 A/C Radiator Damper Servo
Sub–Assembly
A28
No. 4 A/C Radiator Damper Servo
Sub–Assembly
TP
DEF
FACE
GND
VZ
HOT
COOL
M
AD2
LG
W–R