
D37
D30
D12
D29
D17
D16
D13
D14
D8
D9
D7
* 4:Before May 2014 Production
D18
D24
D19
D23
D22
D26
D39
D21
D20
D6
D5
D34
D32
D33
D36
D35
D31
D28
D27
D25
D10
D4
(*4)
D2
D3

D 2 Light Control Rheostat
D 3 Headlight Leveling Switch
D 4 Luggage Door Opening Switch Assembly
D 5 Main Body ECU
D 6 Main Body ECU
D 7 Combination Meter Assembly
D 8 Junction Connector
D 9 Junction Connector
D 10 DLC3
D 12 Radio Receiver Assembly
D 13 Radio Receiver Assembly
D 14 Radio Receiver Assembly
D 16 Junction Connector
D 17 Junction Connector
D 18 Clock Assembly
D 19 A/C Control Assembly
D 20 A/C Control Assembly
D 21 No. 3 Heater Control Sub-Assembly
D 22 Heater Control Sub-Assembly
D 23 Heater Control Sub-Assembly
D 24 Heater Control Base Sub-Assembly
D 25 Engine Switch
D 26 Indoor Electrical Key Oscillator
D 27 Airbag ECU Assembly
D 28 Shift Lever Assembly
D 29 Option Connector
D 30 Passenger Side Squib Circuit (Instrument Panel Passenger Airbag without Door Assembly)
D 31 Parking Brake Switch Assembly
D 32 Seat Heater Switch LH
D 33 Seat Heater Switch RH
D 34 No. 2 Power Outlet Socket Assembly
D 35 Pattern Select Switch Assembly
D 36 Shift Position Indicator
D 37 Airbag Cut Off Switch Cylinder Sub-Assembly
D 39 Front No. 2 Speaker Assembly RH

D 2
White



D 3
White



D 4
White



D 5
White



D 6
White



D 7
White



D 8
Blue



D 9
Blue



D 10
White



D 12
White



D 13
White



D 14
White



D 16
Black



D 17
Black



D 18
White



D 19
White



D 20
White



D 21
White



D 22
White



D 23
White



D 24
White



D 25
White



D 26
White



D 27
White



D 28
White



D 29
White



D 30
White



D 31
White

D 32
White



D 33
White



D 34
White



D 35
White



D 36
White



D 37
White

D 39
White