(Cont. next page)




SRS (RHD)
* 1 : Before Oct. 2011 Production
* 2 : From Oct. 2011 Production
5
6
7
8
M15(A), M31(B)
No. 2 Side Airbag Sensor Assembly RH
BCR+
BCR–
BDR+
BDR–
(Shielded)
M8(A), M30(B)
Side Airbag Sensor
Assembly RH
BBR+
BBR–
BBD+
BBD–
G13(A), M6(B), N10(C)
Center Airbag Sensor Assembly
E1
E2
CANH
CANL
Multiplex Communication
System (CAN RHD)<2–45>
G74
Junction Connector
G2
G1
M27
Junction Connector
M1
N20
Front Floor Side
Airbag Sensor
BER+
BER–
MN1
KM3
K9
Door Side Airbag Sensor RH
(BAT)
10A
ECU–B
(IG)
7. 5A
MET
G19
Combination Meter Assembly
IG2
EP
SRS
G3