
* 3:Before Oct. 2011 Production
* 4:From Oct. 2011 Production
N14
N31
N12
N4
N35
N8
N27
N33
N3
N13
(*3)
N36
(*4)
N11
N20
N18
N30
N26
N19
N28
N32
N16
N7
N15
(*3)
N37
(*4)
N21
N17
N29
N6
N2
N1

N 1 Outside Luggage Electrical Key Antenna
N 2 Power Slide Back Door Warning Buzzer
N 3 Front Door Courtesy Light Switch Assembly LH
N 4 Rear Door Courtesy Light Switch Assembly LH
N 6 Rear Combination Light Assembly LH
N 7 Rear Height Control Sensor Sub-Assembly LH
N 8 Curtain Shield Airbag Assembly LH
N 11 Front Seat Outer Belt Assembly LH
N 12 Curtain Shield Airbag Assembly LH
N 13 Side Airbag Sensor Assembly LH
N 14 Rear Indoor Electrical Key Oscillator
N 15 No.2 Side Airbag Sensor Assembly LH
N 16 Door Control Relay LH
N 17 Fuel Lid Courtesy Switch
N 18 Back Door Motor Unit
N 19 Fuel Pump , Fuel Sender Gauge Assembly
N 20 Front Floor Side Airbag Sensor
N 21 Rear Floor Side Airbag Sensor
N 26 Diode (Slide Door Courtesy Switch LH)
N 27 Diode (Luggage Compartment Light)
N 28 Junction Connector
N 29 Junction Connector
N 30 Junction Connector
N 31 Junction Connector
N 32 Junction Connector
N 33 Multiplex Network Door ECU
N 35 Rear No.3 Speaker Assembly LH
N 36 Side Airbag Sensor Assembly LH
N 37 No.2 Side Airbag Sensor Assembly LH

N 1
White



N 2
Black

N 3
White

N 4
White

N 6
White



N 7
Black



N 8
Black



N 11
Yellow



N 12
Black



N 13
Yellow



N 14
Black

N 15
Yellow



N 16
White



N 17
White

N 18
White



N 19
Gray

N 20
Yellow



N 21
Yellow



N 26
White



N 27
Black

N 28
White



N 29
Blue



N 30
White



N 31
Gray



N 32
Black



N 33
White



N 35
White

N 36
Yellow



N 37
Yellow