
R3
Rear No. 1 Roof Speaker Assembly LH
R4
Rear No. 1 Roof Speaker Assembly RH
RG3
FG4
LI+
LI–
RI+
RI–
F7
Radio Setting Condenser
LO–
LO+
RO–
RO+
RIN
ROUT
LIN
LOUT
F3(A), F4(B), F6(C), F13(D)
Radio Receiver Assembly
RR+
RR–
RL+
RL–
GND
FR+
FR–
FL+
FL–
FN1
GF3
FG3
GM1
LN1
KM1
F8(A), F9(B)
Junction Connector
GF1
HG1
G3
L13
Junction Connector
K13
Junction Connector
L10
No. 1 with Box Speaker Assembly LH
K10
No. 1 with Box Speaker Assembly RH
H2
Front No. 3 Speaker Assembly RH
H3
Front No. 3 Speaker Assembly LH





* 2 : w/ Rear Display
* 5 : Before Aug. 2010 Production
* 6 : From Aug. 2010 Production
* 7 : Before Oct. 2011 Production
* 8 : From Oct. 2011 Production



∗ 2 : w/ Rear Display
∗ 3 : Shielded
∗ 4 : w/ Steering Pad Switch
∗ 7 : Before Oct. 2011 Production
∗ 8 : From Oct. 2011 Production

F 1
White



(From Jun. 2009 Production)

F 3
White



F 4
White

F 6
White



F 7
White



F 8
White



F 9
White



F 13
White

G 3
Black



G 86
Black



H 2
White



H 3
White



I 1
White

J 1
White

K 10
White

K 13
Black



L 10
White

L 13
Black



N 29
Blue



N 31
Gray



N 32
Black



R 3
White

R 4
White

S 2
White



z 7
White



5D
White



LF
Gray




LG
White
1 2 3 4 5 6 7 8 9 10 11 12


LI
White
1 2 3 4 5 6 7 8 9 10 11 12


AG3
Gray


FG2
Gray


FG3
White


FG4
Gray


FN1
White

GF1
White



GF3
Gray



GM1
White



GN1
White



GN2
White



HG1
White



IG1
White




JG1
White
KM1
White
LN1
White
RG3
Gray
SN1
White
SN3
Gray