
L4
K3
K8
K1
K15
K2
K7
K4
L14
L8
L1
L3
L2
L10
L6
L7
L13
L12
L9
L5
K10
K6
K13
K5
K12
K9

| | | |
|---|---|---|
| K | 1 | Rear Power Window Regulator Switch Assembly RH |
| K | 2 | Rear Power Window Regulator Motor Assembly RH |
| K | 3 | Slide Door Lock Remote Control Assembly RH |
| K | 4 | Rear Door Lock Assembly RH |
| K | 5 | Door Control Relay RH |
| K | 6 | Power Slide Door Sensor Assembly RH |
| K | 7 | Slide Door Lock Release Motor Assembly RH |
| K | 8 | Slide Door Handle Switch RH |
| K | 9 | Door Side Airbag Sensor RH |
| K | 10 | No.1 with Box Speaker Assembly RH |
| K | 12 | Junction Connector |
| K | 13 | Junction Connector |
| K | 15 | Rear No.2 Speaker Assembly RH |

| | | |
|---|---|---|
| L | 1 | Rear Power Window Regulator Switch Assembly LH |
| L | 2 | Rear Power Window Regulator Motor Assembly LH |
| L | 3 | Slide Door Lock Remote Control Assembly LH |
| L | 4 | Rear Door Lock Assembly LH |
| L | 5 | Door Control Relay LH |
| L | 6 | Power Slide Door Sensor Assembly LH |
| L | 7 | Slide Door Lock Release Motor Assembly LH |
| L | 8 | Slide Door Handle Switch LH |
| L | 9 | Door Side Airbag Sensor LH |
| L | 10 | No.1 with Box Speaker Assembly LH |
| L | 12 | Junction Connector |
| L | 13 | Junction Connector |
| L | 14 | Rear No.2 Speaker Assembly LH |

K 1
White




K 2
White




K 3
Black

K 4
White




K 5
White




K 6
Dark Gray

K 7
White




K 8
White




K 9
Yellow




K 10
White

K 12
Blue




K 13
Black




K 15
White




L 1
White




L 2
White




L 3
Black

L 4
White




L 5
White




L 6
Dark Gray

L 7
White

L 8
White




L 9
Yellow




L 10
White




L 12
Blue




L 13
Black




L 14
White