(Cont. next page)

Remote Control Mirror (RHD)

∗1 : w/ Retractor Mirror




Remote Control Mirror (RHD)
* 1 : w/ Retractor Mirror
5
6
7
8
I12
Outer Mirror Switch Assembly
Down
Up
Right
Left
Unfold
Auto
Fold
VL
HL
E
MAT
MR
(ACC)
5A
ECU–ACC
F99
No. 13
Junction
Connector
F105(A), F106(B)
No. 22
Junction
Connector
Main Body ECU
<11–40>
MV
MH
MF
M+
J7
Outer Rear View Mirror Assembly LH
MC