
(BAT)
15A
DEICER
(IG)
10A
ECU–IG1
NO. 4
(IG)
10A
ECU–IG1
NO. 4
F107(A)
No. 23 Junction
Connector
F98
No. 12 Junction
Connector
DEICER
Relay
F98
No. 12 Junction
Connector
F103(A),
F104(B)
No. 21
Junction
Connector
F107(A), F108(B)
No. 23 Junction
Connector
F96
No. 10 Junction
Connector
A64
Windshield Deicer (Windshield Glass)
F73(B)
A/C Amplifier
Assembly
Deicer Switch
F61
A/C Control Assembly
F97
No. 11 Junction
Connector
A76
No. 3 Ground
Junction Connector
AF
FC
FC

A64
Black

90980-11155

A76
Black



90980-12B56

F61
Black



82824-33470

F73
White



90980-12760

F96
Black



90980-12B54

F97
Black



90980-12B54

F98
Black



90980-12B54

F103
White



90980-12372

F104
White



90980-12372

F107
White



90980-12372

F108
White



90980-12372

3A
White



90980-12943

3D
White



90980-12A48


3F
White
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32

90980-12A47