
(*1)
E2
E1
E14
E15
E12
E11
E26
E37
* 1:w/o Entry & Start System
E6
E7
E5
E8
E9
E13
E3
E4
E24
E38
E39
E29
E23
E10
E21
E25
E17
E18
E16
E20
E19
E22
E27
E30
E28
E32
(*1)
E33
E31
E35
E34

E 1 Diode (Door Courtesy Rear LH)
E 2 Diode (Door Courtesy Rear RH)
E 3 Outer Mirror SW
E 4 Headlamp Cleaner SW
E 5 Diode (Door Courtesy Front LH)
E 6 Main Body ECU
E 7 Main Body ECU
E 8 Main Body ECU
E 9 Main Body ECU
E 10 DLC3
E 11 Automatic Light Control Sensor
E 12 Ion Generator
E 13 VSC Warning Buzzer
E 14 Turn Signal Flasher
E 15 Transponder Key ECU
E 16 Airbag Squib (Steering Wheel Pad)
E 17 Steering Sensor
E 18 Spiral Cable
E 19 Windshield Wiper SW Assembly
E 20 Windshield Wiper SW Assembly
E 21 Headlamp Dimmer SW Assembly
E 22 Unlock Warning SW
E 23 Ignition SW
E 24 Key Interlock Solenoid
E 25 Transponder Key Amplifier
E 26 Windshield Wiper Relay
E 27 A/C Room Temp. Sensor
E 28 Cigarette Lighter
E 29 Power Outlet Socket (Front)
E 30 Airbag Sensor Assembly Center
E 31 Transmission Control SW
E 32 Shift Lock Control ECU
E 33 Parking Brake SW
E 34 Yaw Rate Sensor
E 35 Power Outlet Socket (Rear)
E 37 Diode (Door Courtesy Front RH)
E 38 A/C Amplifier
E 39 Blower Motor

E 1
Black

E 2
Black

E 3
White



E 4
White



E 5
Black

E 6
White



E 7
White



E 8
White



E 9
White



E 10
Black



E 11
Blue



E 12
White



E 13
Black

E 14
Black



E 15
White



E 16
Yellow



E 17
Black



E 18
Black

E 19
White



E 20
White

E 21
White



E 22
White



E 23
White



E 24
Black

E 25
Black



E 26
White



E 27
Black



E 28
White

E 29
White



E 30
Yellow



E 31
White



E 32
White



E 33
White

E 34
Black



E 35
White



E 37
Black

E 38
White



E 39
White