ANTI–LOCK BRAKE SYSTEM

DI284–15

HOW TO PROCEED WITH TROUBLESHOOTING

Troubleshoot in accordance with the procedure on the following pages.



Step 2, 5, 8, 9, 11: Diagnostic steps permitting the use of the hand–held tester or break–out–box.

★: Refer LAND CRUISER Chassis and Body Repair Manual (Pub. No. RM616E).