
(IG)
7.5A
IG1
(BAT)
10A
STRG
HTR
(IG)
10A
ECU-IG
NO.2
IG
INDC
RC
G152
Steering Heater Switch
A65
Junction
Connector
A69
Junction
Connector
z14(B)
Steering Wheel Heater Control Assembly
Steering Heater
Steering Heater Controller
BTM
EHT
ETM
BHT
G151(A),z14(B)
Spiral Cable Sub-Assembly
STRG HTR
Relay
G126(A),G127(B),
G140(C),G141(D)
Junction Connector
GA1
(RHD)
(LHD)
A70
Junction
Connector
G104
Junction Connector
A1
G3

A65
White



A69
White



A70
White



G104
White



G126
Black



G127
Black



G140
Black



G141
Black



G151
Black



G152
Blue



z14
White



2D
White



2F
White



3A
White



3B
White



GA1
White