
C165
D11
r7
r8
C168
C167
C166
C169
C170
p1
r4
D8
D10
D9
r5
p2
r9
r6
C164

C164 Generator Assembly
C165 Glow Plug Assembly
C166 No. 2 Exhaust Gas Temperature Sensor
C167 No. 3 Exhaust Gas Temperature Sensor
C168 Urea Injector Assembly
C169 No. 1 Exhaust Gas Temperature Sensor
C170 Cam Position Sensor
D 8 Starter Assembly
D 9 Starter Assembly
D 10 Starter Assembly
D 11 Starter Assembly
p 1 Front Speed Sensor RH
p 2 Front Speed Sensor LH
r 4 Viscous Heater with Magnet Clutch ASSY
r 5 Diesel Throttle Body ASSY
r 6 Injection or Supply Pump Assembly (Suction Control Valve)
r 7 Crank Position Sensor
r 8 Fuel Pressure Sensor (Common Rail Assembly)
r 9 Pressure Discharge Valve (Common Rail Assembly)

C164

C165
Gray

90980-10942

C166
Black

90980-10949

C167
Gray

90980-10901

C168
Gray



90980-11875

C169
White

90980-10899

C170
Black

90980-12353

D8

D9



D10
Black

90980-11184

D11
Black

90980-12941

p1
Black

90980-11900

p2
Black

90980-11900

r4
Gray

90980-11271

r5
Black



90980-11858

r6
Gray



90980-12747

r7
Black

90980-12353

r8
Black

90980-11194

r9
Black



90980-12747