
C25
C27
C5
C24
C26
C6
C4
C11
C3
C9
C22
C7
C17
C16
C29
C12
C23
C10
C8
C19
C18
C20
C1
C13
C14
C2
C21

C 1 Fuel Injector Assembly No. 1
C 2 Fuel Injector Assembly No. 2
C 3 Fuel Injector Assembly No. 3
C 4 Fuel Injector Assembly No. 4
C 5 Fuel Injector Assembly No. 5
C 6 Fuel Injector Assembly No. 6
C 7 Ignition Coil Assembly No. 1
C 8 Ignition Coil Assembly No. 2
C 9 Ignition Coil Assembly No. 3
C 10 Ignition Coil Assembly No. 4
C 11 Ignition Coil Assembly No. 5
C 12 Ignition Coil Assembly No. 6
C 13 Throttle Body Assembly
C 14 Crank Position Sensor
C 16 Cam Timing Oil Control Valve (Bank 1 Intake Side)
C 17 Cam Timing Oil Control Valve (Bank 1 Exhaust Side)
C 18 Cam Timing Oil Control Valve (Bank 2 Intake Side)
C 19 Cam Timing Oil Control Valve (Bank 2 Exhaust Side)
C 20 VVT Sensor (Bank 1 Intake Side)
C 21 VVT Sensor (Bank 2 Intake Side)
C 22 VVT Sensor (Bank 1 Exhaust Side)
C 23 VVT Sensor (Bank 2 Exhaust Side)
C 24 E.F.I. Engine Coolant Temperature Sensor
C 25 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
C 26 Air Fuel Ratio Sensor (Bank 2 Sensor 1)
C 27 Oxygen Sensor (Bank 1 Sensor 2)
C 29 Power Steering Oil Pressure Switch

C1
Gray



90980-11875

C2
Gray



90980-11875

C3
Gray



90980-11875

C4
Gray



90980-11875

C5
Gray



90980-11875

C6
Gray



90980-11875

C7
Black



90980-11885

C8
Black



90980-11885

C9
Black



90980-11885

C10
Black



90980-11885

C11
Black



90980-11885

C12
Black



90980-11885

C13
Black



90980-11858

C14
Black



90980-12028

C16
Black

90980-11162

C17
Black

90980-11162

C18
Black

90980-11162

C19
Black

90980-11162

C20
Black

90980-12353

C21
Black

90980-12353

C22
Black

90980-12353

C23
Black

90980-12353

C24
Black

90980-10735

C25
Dark Gray

90980-10869

C26
Dark Gray

90980-10869

C27
Dark Gray

90980-10869

C29
Gray

90980-11451