
C1
C2
C3
C4
C43
C73
C30
C76
C86
C72
C74
C79
C89
C88
C83
C80
C33
C87
C46
C39
C65
C24
C84
C82
C71
C85
C77
C52
C70
C57

C 1 Fuel Injector Assembly No. 1
C 2 Fuel Injector Assembly No. 2
C 3 Fuel Injector Assembly No. 3
C 4 Fuel Injector Assembly No. 4
C 24 E.F.I. Engine Coolant Temperature Sensor
C 30 Electronically Controlled Transmission Solenoid
C 33 Intake Mass Air Flow Meter Sub-Assembly
C 39 Cooler Compressor Assembly
C 43 Transfer Shift Actuator Assembly
C 46 Engine Oil Level Sensor
C 52 Cam Position Sensor
C 57 Power Steering Oil Pressure Switch
C 65 Generator Assembly
C 70 Crank Position Sensor
C 71 Suction Control Valve
C 72 Pressure Discharge Valve
C 73 Diesel Throttle Body Assembly
C 74 Diesel Throttle Body Assembly
C 76 Electric Vacuum Regulating Valve Assembly
C 77 VSV (for EGR Cut)
C 79 VSV (for No. 2 Swirl Control Valve)
C 80 VSV (for Engine Mounting)
C 82 Fuel Pressure Sensor
C 83 Vacuum Sensor (Diesel Turbo Pressure Sensor)
C 84 Intake Air Temperature Sensor
C 85 Fuel Temperature Sensor
C 86 Electric EGR Control Valve Sensor
C 87 Nozzle Vane Position Sensor
C 88 Injector Driver
C 89 Injector Driver

C1
Gray



90980-11875

C2
Gray



90980-11875

C3
Gray



90980-11875

C4
Gray



90980-11875

C24
Black

90980-10735

C30
Gray



90980-12293

C33
Black

90980-12292

C39
Gray

90980-11016

C43
Black



90980-11664

C46
Gray

90980-11235

C52
Black

90980-10947

C57
Black

90980-11428

C65
Black

90980-11964

C70
Gray

90980-11016

C71
Gray

90980-11285

C72
Black

90980-11162

C73
Black

90980-11261

C74
Black

90980-11145

C76
Brown

90980-11162

C77
Brown



90980-11149

C79
Brown



90980-11149

C80
Brown

90980-10617

C82
Black

90980-11194

C83
Black

90980-10845

C84
Gray

90980-11025

C85
Dark Gray

90980-10737

C86
Black

90980-11143

C87
Black



90980-12303

C88
Dark Gray

90980-11144

C89
Gray

90980-12520