

* 3:Cold Area Spec.
* 4:Except Cold Area Spec.

B 5 Fog Light Assembly LH
B 6 Fog Light Assembly RH
B 9 No.1 Ultrasonic Sensor RH
B 10 No.1 Ultrasonic Sensor LH

D 12 Starter Assembly
D 13 Starter Assembly

j 1 Generator Assembly
j 2 Generator Assembly

z 17 Front Speed Sensor RH
z 18 Front Speed Sensor LH
z 29 Winch Main Relay (No.1 Magnet Switch Assembly)
z 30 Winch Main Relay (No.1 Magnet Switch Assembly)
z 31 With Magnet Switch Winch Motor Assembly
z 32 With Magnet Switch Winch Motor Assembly
z 33 With Magnet Switch Winch Motor Assembly
z 34 Front Height Control Sensor Sub-Assembly RH
z 35 Front Height Control Sensor Sub-Assembly LH
z 64 Suction Control Valve (Injection or Supply Pump Assembly)
z 65 Fuel Temperature Sensor (Injection or Supply Pump Assembly)
z 66 DC Motor and Nozzle Vane Position Sensor LH
z 67 DC Motor and Nozzle Vane Position Sensor LH
z 68 Pressure Discharge Valve
z 69 Washer Nozzle Sub-Assembly RH
z 70 Washer Nozzle Sub-Assembly LH

B 5
Black



B 6
Black



B 9
Black



B 10
Black



D 12
Black

D 13



j 1



j 2



z 17
Black

z 18
Black

z 29



z 30



z 31



z 32
Gray



z 33



z 34
Black



z 35
Black



z 64
Gray

z 65
Gray

z 66
Black



z 67
Gray



z 68
Gray



z 69
Gray



z 70
Gray