
ED00R–02



REMOVAL

REMOVE ACCELERATOR PEDAL ASSEMBLY

(a) Disconnect the 2 connectors.

(b) Remove 3 bolts and accelerator pedal assembly.