



STARTING

PP1TD–01

SST (Special Service Tools)

	09286–46011	Injection Pump Spline Shaft Puller	Armature front and rear bearing for 2.5 kW Armature rear bearing for 3.0 kW
	09810–38140	Starter Magnet Switch Nut Wrench 14	
	09810–38170	Starter Magnet Switch Nut Wrench 17	
	09820–00030	Alternator Rear Bearing Replacer	
	09950–00020	Bearing Remover	Armature front bearing for 3.0 kW