ED05R–01

INSTALLATION

INSTALL INTAKE MANIFOLD WITH INTAKE AIR CONTROL VALVE

(See page EM–36)