(Cont. next page)



(Cont. next page)

Multiplex Communication System (Body Control LHD)



4 PRIUS PLUG–IN HYBRID (Cont' d)

(Cont. next page)



(Cont. next page)



4 PRIUS PLUG–IN HYBRID (Cont' d)

(Cont. next page)

Multiplex Communication System (Body Control LHD)



(Cont. next page)

Multiplex Communication System (Body Control LHD)



4 PRIUS PLUG–IN HYBRID (Cont' d)

(Cont. next page)



(Cont. next page)

Multiplex Communication System (Body Control LHD)



4 PRIUS PLUG–IN HYBRID (Cont' d)

(Cont. next page)

Multiplex Communication System (Body Control LHD)



(Cont. next page)

Multiplex Communication System (Body Control LHD)



When wiring colors are indicated with (**), either the colored wiring (general wiring) or the painted wiring is used.

4 PRIUS PLUG–IN HYBRID (Cont' d)