* 6:8 Speaker
* 7:6 Speaker



H	1	Front Passenger Side Squib Circuit
I	1	Automatic Light Control Sensor
I	2	Front No. 2 Speaker Assembly RH
I	3	Front No. 2 Speaker Assembly LH
I	4	Instrument Panel Speaker RH (No. 2 Instrument Panel Speaker Panel Sub-Assembly)
I	5	Instrument Panel Speaker LH (No. 2 Instrument Panel Speaker Panel Sub-Assembly)
M	1	Passenger Seat Belt Warning Light Assembly
R	1	Airbag ECU Assembly
S	1	Airbag ECU Assembly
b	1	Transmission Shift Main Switch
z	5	Shift Lever Position Sensor
z	6	No. 2 Shift Lever Position Sensor
z	8	Driver Side Squib Circuit , Spiral Cable Sub-Assembly
z	9	Spiral Cable Sub-Assembly , Steering Pad Switch Assembly
z	10	Cruise Control Main Switch , Spiral Cable Sub-Assembly
z	11	A/C Amplifier Assembly , A/C Blower Assembly
z	14	Power Steering ECU Assembly , Power Steering Torque Sensor
z	15	Power Steering ECU Assembly , Power Steering Motor Assembly
z	16	Power Steering ECU Assembly , Power Steering Motor Assembly
z	29	Extension Module
z	30	Radio & Display Receiver Assembly
z	31	Radio & Display Receiver Assembly

H 1
Orange



I 1
Black



I 2
White



I 3
White



I 4
White



I 5
White



M 1
White



R 1
Yellow



S 1
Yellow



b 1
White



z 5
White



z 6
White



z 8
Orange



z 9
White



z 10
White



z 11
White



z 14
White



z 15
White



z 16
White



z 29
White



z 30
White



z 31
White