(Cont. next page)

ABS, TRC, VSC



:There is no wire color information.

* 1 :Except Korea
* 2 :Korea

(Cont. next page)

ABS, TRC, VSC




ABS, TRC, VSC
9
10
11
12
(IG)
(BAT)
5A ECU-IG1 NO.2
5A ECU-DCC NO.1
5A METER-IG2
10A ECU-DCC NO.2
A41 Brake Booster with Master Cylinder Assembly
IG1
BAT
ESS
CANH
CANL
LBL
CA1H
CA1L
CA2H
CA2L
GND
F55 Steering Sensor
Multiplex Communication System (CAN)<2-11>
A44 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Assembly)
A56 No. 1 Ground Junction Connector
A57 No. 2 Ground Junction Connector
F75(A) No. 7 Junction Connector
F76(B) No. 13 Junction Connector
F74(A) No. 6 Junction Connector
F79(B) No. 11 Junction Connector
F6(A) Combination Meter Assembly
IG+
5V +B
5V IC
Telltales
LED Driver
Buzzer
I/F
Display Driver
CPU
CAN I/F
ES
F53 No. 15 Junction Connector
F75 No. 7 Junction Connector
Multiplex Communication System (CAN)<2-15>