

2. Construction

The configuration of the engine control system is as shown in the following chart.



(Continued)


053EG08Y



053EG09Y

(Continued)

NF



*1: Models with Dynamic Laser Cruise Control System
*2: Models with Cruise Control System