


4. Layout of Main Components



053EG23Y



053EG24Y


Combination Meter
● MIL (Malfunction Indicator Lamp)
Mass Air Flow Meter
● Intake Air Temperature Sensor
ECM
VSV
(For Air Intake Control)
Fuel Pump
Canister
● Vent Valve
● Leak Detection Pump
● Canister Pressure Sensor
Heated Oxygen Sensor
(Bank 2, Sensor 2)
DLC3
Actuator
(For Air Intake Control)
Accelerator Pedal
Position Sensor
Heated Oxygen Sensor
(Bank 1, Sensor 2)

053EG25Y