
Power Outlet (12V Rear)



○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
P18	44				

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1P	31	Floor No.1 Wire and Driver Side J/B (Lower Finish Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
BH	54	Under the Left Center Pillar