

(BAT)
10A
HORN
1
3
HORN
Relay
2
5
8
2H
7
2F
G–B
25
1C
11
1H
G–B
6
HO
Spiral
Cable
L
1
Horn SW
C13
Combination SW
G–W
G–W
1
H10
Horn (High)
1
H11
Horn (Low)

○ : **Parts Location**

Code	See Page	Code	See Page	Code	See Page
C13	39	H10	36	H11	36

: **Junction Block and Wire Harness Connector**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	31	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
1H	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2F	24	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2H		