

PARTS LOCATION




N

A162046E02

ES


VVT SENSOR (BANK 1 INTAKE SIDE)
VVT SENSOR (BANK 2 INTAKE SIDE)
CAMSHAFT TIMING OIL CONTROL VALVE ASSEMBLY (BANK 1 INTAKE SIDE)
CAMSHAFT TIMING OIL CONTROL VALVE ASSEMBLY (BANK 2 INTAKE SIDE)
IGNITION COIL WITH IGNITER
ENGINE COOLANT TEMPERATURE SENSOR
FUEL INJECTOR
AIR FUEL RATIO SENSOR (BANK 2 SENSOR 1)
VVT SENSOR FOR EXHAUST CAMSHAFT (BANK 2 EXHAUST SIDE)
CRANKSHAFT POSITION SENSOR
VVT SENSOR (BANK 1 EXHAUST SIDE)
AIR FUEL RATIO SENSOR (BANK 1 SENSOR 1)
CAMSHAFT TIMING OIL CONTROL VALVE ASSEMBLY (BANK 1 EXHAUST SIDE)
CAMSHAFT TIMING OIL CONTROL VALVE ASSEMBLY (BANK 2 EXHAUST SIDE)
Y
A114586E21



Y

A114543E14