
STARTING SYSTEM

PARTS LOCATION



ST

SYSTEM DIAGRAM

The starting system rotates the starter motor according to the signals from the ignition switch and PNP switch.

