

AUTOMATIC TRANSAXLE UNIT

COMPONENTS



AX




N*m (kgf*cm, ft.*lbf): Specified torque ● Non-reusable part Precoated part

N

C114872E09

AX




N*m (kgf*cm, ft.*lbf): Specified torque ● Non-reusable part


N

C114873E13

AX


FRONT PLANETARY GEAR ASSEMBLY
FRONT PLANETARY RING GEAR
FLANGE
PLATE
SNAP RING
BRAKE HUB
SNAP RING
DISC
2ND BRAKE PISTON ASSEMBLY
REAR PLANETARY SUN GEAR ASSEMBLY
THRUST BEARING RACE
1-WAY CLUTCH ASSEMBLY
1-WAY CLUTCH SLEEVE OUTER
REAR PLANETARY GEAR ASSEMBLY
THRUST BEARING RACE NO.2
THRUST NEEDLE ROLLER BEARING
INPUT SUN GEAR
1-WAY CLUTCH INNER RACE
PLANETARY CARRIER THRUST WASHER NO.2
SNAP RING
THRUST NEEDLE ROLLER BEARING
THRUST NEEDLE ROLLER BEARING
PLANETARY CARRIER THRUST WASHER NO.1
TRANSAXLE REAR COVER
DIRECT CLUTCH ASSEMBLY
THRUST BEARING RACE
● NEEDLE ROLLER BEARING
REAR CLUTCH OIL SEAL RING OUTER
THRUST BEARING
OVERDRIVE DIRECT CLUTCH HUB SUB-ASSEMBLY
● Non-reusable part
N
C114874E03

AX


UNDERDRIVE BRAKE PISTON
UNDERDRIVE CLUTCH ASSEMBLY
FLANGE
PLATE
● NEEDLE ROLLER BEARING
SNAP RING
THRUST NEEDLE ROLLER BEARING
BEARING RACE
DISC
UNDERDRIVE 1 WAY CLUTCH ASSEMBLY
UNDERDRIVE CLUTCH DRUM OIL SEAL RING
SNAP RING
THRUST BEARING
● O-RING
UNDERDRIVE PLANETARY GEAR ASSEMBLY
UNDERDRIVE BRAKE RETURN SPRING SUB-ASSEMBLY
THRUST BEARING UNDERDRIVE RACE NO.2
PARKING LOCK PAWL
PAWL SHAFT CLAMP
9.8 (100, 87 in.*lbf)
TENSION SPRING
PARKING LOCK PAWL SHAFT
PARKING LOCK PAWL PIN
DIFFERENTIAL GEAR ASSEMBLY
CLUTCH APPLY TUBE
BRAKE APPLY TUBE
5.4 (55, 48 in.*lbf)
TRANSAXLE APPLY TUBE CLAMP
N*m (kgf*cm, ft.*lbf): Specified torque
● Non-reusable part
● GOVERNOR APPLY GASKET NO.1
N
C114865E02

AX