ANTI-LOCK BRAKE SYSTEM

PARTS LOCATION



BC

HOW TO PROCEED WITH TROUBLESHOOTING

The intelligent tester can be used at steps 3, 7, 10, and 13.

1	**VEHICLE BROUGHT TO WORKSHOP**

NEXT

2	**CUSTOMER PROBLEM ANALYSIS**

(a) Interview the customer to confirm the trouble.

NEXT

3	**DTC CHECK/CLEAR AND FREEZE FRAME DATA**

NEXT

4	**PROBLEM SYMPTOM CONFIRMATION**

NEXT

5	**PROBLEM SYMPTOM SIMULATION**

- **SYMPTOM DOES NOT OCCUR: GO TO STEP 6**
- **SYMPTOM OCCURS: GO TO STEP 7**

6	**SYMPTOM SIMULATION**

NEXT

7	**DTC CHECK**

(a) Check for output DTCs (See page BC-10).

- **NORMAL SYSTEM CODE: GO TO STEP 8**
- **TROUBLE CODE: GO TO STEP 9**

8	**PROBLEM SYMPTOMS TABLE**

NEXT

GO TO STEP 10

9	**DTC CHART**

NEXT

10	**CIRCUIT INSPECTION**

NEXT

11	**IDENTIFICATION OF PROBLEM**

NEXT

12	**REPAIR OR REPLACE**

NEXT

13	**CONFIRMATION TEST**

NEXT

END