INSTALLATION

1. **INSTALL LASER SENSOR**
   NOTICE:
   Do not install the laser sensor if it has been damaged or received some sort of shock.
2. **INSTALL FRONT BUMPER REINFORCEMENT SUB-ASSEMBLY (See page ET-9)**