DOOR COURTESY LIGHT (for Rear Side)

ON-VEHICLE INSPECTION

1. REAR DOOR COURTESY LIGHT ASSEMBLY LH

(a) Check that the exists between the terminals.
Resistance:
Below 1 Ω

2. REAR DOOR COURTESY LIGHT ASSEMBLY RH

(a) Check that the exists between the terminals.
Resistance:
Below 1 Ω