CUSTOMIZE PARAMETERS

1. Seat Belt Buzzer ON/OFF Setting

The seat belt buzzer ON/OFF setting, which is a setting of the buzzer function of the combination meter, can disable the driver side seat belt buzzer and front passenger side seat belt buzzer.

NOTICE:

These buzzers should be on for safe driving. Perform the procedures only if it is necessary to set the buzzer off.

(a) Driver side and passenger side seat belt buzzers
- (1) Turn the ignition switch to the ON position.
- (2) Press the ODO/TRIP switch until the odometer appears.
- (3) Turn the ignition switch off.
- (4) Turn the ignition switch to the ON position.
- (5) Press the ODO/TRIP switch immediately (within 6 seconds) and hold it down for 10 seconds or more.
- (6) Continue holding down the ODO/TRIP switch and fasten the driver side seat belt.
- (7) Check that the odometer displays either "b-ON" or "b-OFF"
- (8) Press the ODO/TRIP switch to change the display to "b-OFF".
- (9) Turn the ignition switch off.
- (10) Turn the ignition switch to the ON position.
- (11) Check that no buzzer sounds when the vehicle speed is 20 km/h (12 mph) or more and the driver seat belt is unfastened.

(b) Front passenger side seat belt buzzer
- (1) Turn the ignition switch to the ON position.
- (2) Press the ODO/TRIP switch until the odometer appears.
- (3) Turn the ignition switch off.
- (4) Turn the ignition switch to the ON position.
- (5) Sit in the front passenger seat. Press the ODO/TRIP switch immediately (within 6 seconds) and hold it down for 10 seconds or more.
- (6) Continue holding down the ODO/TRIP switch and fasten the passenger side seat belt.
- (7) Check that the odometer displays either "b-ON" or "b-OFF"
- (8) Press the ODO/TRIP switch to change the display to "b-OFF".
- (9) Turn the ignition switch off.
- (10) Turn the ignition switch to the ON position.

(11)Check that no buzzer sounds when the vehicle speed is 20 km/h (12 mph) or more and the front passenger seat belt is unfastened.
HINT:
"b-OFF" indicates that the buzzer is OFF. "b-ON" indicates that the buzzer is ON. The buzzer ON/OFF setting will be finished (the odometer will appear) if the ODO/TRIP switch is not operated for 10 seconds or more. In this case, perform step 11 to check that the buzzer ON/OFF setting is complete. If it is not complete, start from step 1 again.
NOTICE:
- **When either the battery cable or the combination meter connector is disconnected, these buzzers are set on.**
- **ODO/TRIP meter returns to 0 after starting this procedure, although it is not displayed.**