Pressing Power Switch does not Turn on System

INSPECTION PROCEDURE

1	CHECK VEHICLE CONDITION

(a) Check that conditions in the cabin are not likely to cause condensation.
HINT:
This problem occurs when the cabin is humid and the temperature changes rapidly. This may produce condensation, resulting in a short circuit.
OK:
Condensation is not likely to be produced.

NG → **DRY OUT CABIN AND RECHECK CONDITION**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

No Sound can be Heard from Speakers

INSPECTION PROCEDURE

1	CHECK RADIO RECEIVER

(a) Check radio receiver setting.
  (1) Check that the volume is not set to "0".
  (2) Check that "MUTE" is off.
  OK:
  The volume is not set to "0" and "MUTE" is off.

OK → **END**

NG

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE