DTC	44-43	DVD-ROM Abnormal

DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
44-43	DVD-ROM operation is abnormal.	• DVD • Television display assembly

INSPECTION PROCEDURE

HINT:
After the inspection is completed, clear the DTCs.

1 CHECK IF A PROPER DVD IS INSERTED

(a) Make sure that the DVD is a video DVD or a CD with an MP3 file, and that it is not deformed, flawed, stained, burred, or otherwise defective.
OK:
Normal DVD or CD
HINT:
- Translucent or uniquely-shaped DVDs or CDs cannot be played.
- For details on playable DVDs or CDs, refer to the Owner's Manual.

NG → **END**

OK

2 CHANGE DISC

(a) Replace the disc with another and recheck.
(1) Replace the disc with another normal one.
(2) Clear the DTCs (See page AV-18).
(3) Recheck for DTCs and check if the same trouble occurs again.
OK:
Malfunction disappears.

NG → **REPLACE TELEVISION DISPLAY ASSEMBLY**

OK

END

DTC	44-44	DVD Error

DTC	44-48	Excess Current

DTC	44-50	Tray Insertion / Ejection Error

DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
44-44	Operation error in the DVD mechanism.	Television display assembly
44-48	Excess current is present in the DVD player.	
44-50	Malfunction in insertion / ejection system.	

INSPECTION PROCEDURE

HINT:
After the inspection is completed, clear the DTCs.

1	CLEAR DTC

(a) Clear the DTCs (See page AV-18).

NEXT

2	RECHECK DTC

(a) Recheck for DTCs and check if the same trouble occurs again.
HINT:
If DTCs are detected frequently, replace the television display assembly.
OK:
Malfunction disappears.

NG → **REPLACE TELEVISION DISPLAY ASSEMBLY**

OK

END