DTC	44-47	High Temperature

DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
44-47	Sensor detects that DVD unit temperature is high. (Over 80°C)	Television display assembly

INSPECTION PROCEDURE

HINT:
After the inspection is completed, clear the DTCs.

1 CHECK TELEVISION DISPLAY ASSEMBLY

(a) Park the vehicle in a cool place.
(b) Check that the temperature of the television display assembly becomes sufficiently low, and start the engine. Check that the malfunction disappears.
OK:
Malfunction disappears.

NG → **REPLACE TELEVISION DISPLAY ASSEMBLY**

OK

END

DTC	44-78	DSP Error

DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
44-78	An error occurs during the decode process (MP3/ WMA).	-

INSPECTION PROCEDURE

HINT:
After the inspection is completed, clear the DTCs.
NOTICE:
- **This code may be output even if there is no malfunction.**
- **If this code is output frequently, replace the television display assembly.**

1	CLEAR DTC

(a) Clear the DTCs (See page AV-18).

NEXT

2	RECHECK DTC

(a) Recheck for DTCs and check if the same trouble occurs again.
OK:
Malfunction disappears.

NG → **REPLACE TELEVISION DISPLAY ASSEMBLY**

OK

END